

USB PSX Bridge

Issue	Changes	Date	Author
1.0	Draft	12 August 2003	James Monaghan

This adapter allows you to use your PlayStation game controller in your computer.

Software Instillation

- 1) Insert the bundled CD into the CD-ROM drive of your computer. If your computer is AutoPlay compatible then go to step 4 to continue with software instillation.
- 2) Go to the Windows task bar and click "Start", the "Run".
- 3) Type "D:\setup.exe" and press the "Enter" key, where "D:" is the designation of your CD-ROM drive.
- 4) Follow the on screen instructions to continue with Rockfire Game Driver software installation.
- 5) Upon completing software instillation, proceed to hardware Instillation.

Hardware Instillation

If you are using a USB hub, be sure that the hub power adapter is used. Otherwise, some USB Hub's will lead to Hardware Instillation failure due to lask of power.

- 1) Plug your AA-1765 USB PSX bridge into any available port/hub.
- 2) Plug in your PlayStation Controller into the USB PSX bridge, now you are ready to play the game.

End of Instillation

Operation Reference

Please note that not all PlayStation Controllers have a vibration function.

For these non-vibration controllers AA-1765 simply allows the PlayStation Controller on your computer.

Mode Button

Offers selection of vibration or non-vibration mode to PlayStation Controller.

"No Light": PlayStation Game Controller in digital mode.

"Green Light": Indicate PlayStation Game Controller in digital mode.

"Red Light": Indicate PlayStation Game Controller in analogue or wheel or non-vibration mode.

"Organge Light": Indicate PlayStation Game Controller in vibration mode.

Play under vibration mode, the AA-1765 will not allow a user to change mode of PlayStation Controller. While

NOTE

For stronger vibration forces of the PlayStation Controller, it is advisable to use an external power adapter of 9V DC, 100MA power adapter.